

Xpressions®SNAP!™ Fabric Graphic Skin Change-Out



1. Remove the existing skin.




2. Remove the o-ring on each hub node. Retain o-ring for replacement.



3. The o-ring can be removed with your fingers, if difficult a round end of a paper clip can help pry it off. Take care not to rip the fabric of the graphic.



4. Remove the skin from hub by gently pulling corner off of the hub node. Repeat steps 2 thru 4 on the remaining three corners. Fold skin and store.




5. Remove replacement skin from its storage bag. Make sure you have all four o-rings from the previous skin.



6. Start at the top left or right hub and push button hole in skin corner over the hub node. Attach the remaining 3 corners the same way.



7. Replace o-ring over node. Replace o-ring on remaining 3 hub nodes.



8. The o-ring prevents the skin from rotating when frame is collapsed. A single hub node may have up to 4 skin corners attached to it.



9. Replacement of other skins shapes, i.e., 1x3 or skin styles, i.e., double twists, uses the same concept. Change your skins, or remove to wash if dirty, once you've done it once it's simple. For complex skin configurations retain original photo or take a photo to help map replacement.